



Vetzeria Vistosi Srl · Via G. Galilei, 9-9/A-11 · 31021 Mogliano V.to · Treviso · Italy  
 P. Iva IT02497840278 · Cap. Soc. € 100.000,00 I.V. · N° R.E.A. TV - 170728  
 Cod. Fisc. - P.I. N° 01808840266 · Iscr. Reg. AEE N° IT08010000000170  
 Tel. +39 041 5900170 - 041 5903480 · Fax +39 041 5900992 - 041 5904540  
 vetreriavistosi@legalmail.it · www.vistosi.it · vistosi@vistosi.it



## English

### ASSEMBLY INSTRUCTION

Check there is no network voltage before installing the equipment.

- Attach to the ceiling the component (1) with the screw (2) and the dowel (3).
- Insert the steel cable (4) into the particular (5) and screw it to the component (1).
- Once established the length of the rope, let come out the rope from the component (1) and screw the component (6) to the particular (5) that will block the rope. Ensure with the security sphere (7) the segment that comes out and cut off the excess. (Repeat the operations for the four attachment points).
- Unscrew the component (10) to separate the bracket (9) from the canopy (8).
- Fix to the wall the bracket (9) using the screws (11) and the dowels (12).
- Insert the electrical cable through the hole of the canopy cover (13) and secure it with the clamp inside the canopy (14).
- Connect the network cables to the terminals (15), making sure to insert the yellow/green cable in the terminal marked with the earth symbol.
- Close the canopy (8) by screwing the component (10) to lock it.
- Insert 3 light bulbs G9 (16) into the lamp holders (17).

MINIGIOGALI, RECOMMENDED arrangement:

- Now fit the glass hooks chains starting from the inner layer (18) placing on the metal rod path respectively 2 chains on the shorter side (A) and 9 chains on the longer side (B), composed of a quantity of variable meshes, indicated numerically. Repeat the operations for the opposite sides of the same level, starting from the opposite ends.
- Then follow the indications for the arrangement of the hooks in points (19), (C), (D) and (20), (E), (F), moving towards the outer layers, in order to obtain the result at the point (21).

## Italiano

### ISTRUZIONI PER IL MONTAGGIO

Assicurarsi che non sia presente tensione di rete prima di procedere all'installazione dell'apparecchio.

- Fissare a soffitto il componente (1) tramite la vite (2) e il tassello (3).
- Infilare la fune di acciaio (4) nel particolare (5) ed avvitarlo al componente (1).
- Una volta stabilita la lunghezza della fune farla fuoriuscire dal componente (1) ed avvitare il componente (6) al particolare (5) che bloccherà la fune. Assicurare con la sfera di sicurezza (7) gli spezzoni che fuoriescono e tagliarne l'eccedenza. (Ripetere l'operazione per i quattro punti di fissaggio).
- Svitare il componente (10) per separare la staffa (9) dal rosone (8).
- Fissare a parete la staffa (9) tramite le apposite viti (11) e tasselli (12).
- Infilare il cavo elettrico attraverso il foro del coperchio del rosone (13) e fissarlo con il bloccacavo all'interno del rosone (14).
- Collegare i cavi di rete ai morsetti (15) facendo attenzione di inserire il cavo giallo/verde nel morsetto contrassegnato dal simbolo di terra.
- Chiudere il rosone (8) avvitando il componente (10) per bloccarlo.
- Infilare 3 lampadine G9 (16) nei portalampade (17).

MINIGIOGALI, disposizione CONSIGLIATA:

- Montare ora le catene di ganci in vetro iniziando dal livello più interno (18) disponendo sul percorso in tondino metallico rispettivamente 2 catene sul lato minore (A) e 9 catene sul lato maggiore (B), composte da un quantitativo di maglie variabile, indicato numericamente. Ripetere l'operazione per i lati antistanti dello stesso livello, partendo, questa volta, dagli estremi opposti.
- Seguire poi le indicazioni per la disposizione dei ganci ai punti (19), (C), (D) e (20), (E), (F), spostandosi verso i livelli più esterni, ottenendo quindi il risultato al punto (21).



